

DOUBLE GROUTING METHOD

USING MORGAN'S ARCHITECTURAL RANGE FINE JOINTS POLISHED PORCLAIN & RECTIFIED TILES

1. Ensure grout joints are clean.
2. Mix grout to a smooth toothpaste consistency as directions on the bag.
3. Apply grout with a Marshalltown Steel Backed float or similar. Ensuring that all excess grout is removed from the tile surface. Only work small areas at a time. This will depend on climatic conditions, product knowledge and skill levels.
4. Wash off grout using a Wash Boy System. Remove all excess water.
5. Take dry grout powder from the bag and sprinkle over wet grouted joints. Burnish the dry powder into the wet joints with a scourer system. White pad for porcelain and rectified tiles. Ensure a full, even joint is obtained. Remove excess powder from the tiling and allow to dry. This will depend on climatic conditions and site conditions.
6. Finally, wash all tiles and grout with the Wash Boy system and polish with a towelling cloth.

Please Note:

By applying water via a clean-up method will ensure a bond is achieved between the wet grout and the dry powder. Reference should be made to article "How Cement Works"

Should you require any further information,
please contact our Technical Team on 08 9441 6677 (Response within 24hours)
Geoff Hoddy 0417 144 860 or Bevan Morgan 0422 946 599